

INSTRUCTIONS FOR REMOVING THE CONTROL SECTION FOR SMDH/IMDH/WMDH/OWMDH SERIES



Fig.1 - Control Section inside Blower Heater.

Fig. 2 - Remove top screws.

Bottom pins



Fig.3 – To remove the control section pull top towards you (outward) and up off the 2 bottom pins



Fig. 4 – Once removed it can be inspected and repaired or shipped to Dexon. Must be shipped complete as shown. Do not separate panels when shipping to Dexon.



Fig. 5 – **IMPORTANT:** Plug hole to prevent gases and moisture from entering the area. **CAUTION:** This area may no longer be classified as non hazardous and confined entry procedures must be observed.




Fig.6 - When replacing the control section be sure to replace the insulation over the transition. Do not cover the electrical components.